

Radnoti Quick Disconnect Instructions

A Slide Cap-With hole onto the water line. (Tygon tubing #120159)

B Push the plastic sleeve insert into the end of the Tygon tubing with the fared

end frst. (Catalog #120160)

C Be sure to use 5/16 x 3/16 inch Tygon tubing. (Catalog #120159)

D MOISTEN TIP OF TYGON TUBING before insertion into the threaded glass.

CAUTION: To avoid breakage, do not over tighten the screw cap.



Radnoti Q.D.